

# CONTROLLING YOUR REMOTE



## PROGRAMMING YOUR REMOTE

1. Press the TV Power Key
2. Press and hold SETUP until the LED blinks twice.
3. Enter 9-9-1 using the digit keys on the remote.
4. Aim the remote at your TV and press CH+ repeatedly until the TV turns off.
5. Press and hold SETUP until the LED blinks twice.